MrRoboto

1 How to setup system

1.1 Initial computer settings

- 1. Install ubuntu 12.04 on your computer.
- 2. Install ROS GROOVY according to: http://wiki.ros.org/groovy/Installation/Ubuntu
- 3. Install git, type:
 - \$ sudo apt-get install git (in a terminal window)
 Password is ubuntu for the computer in the robot lab.
- 4. Clone the repository of the project. cd* into a folder where you want the folder containing the code. Type:

 \$ ait clone ait@aithub.com.matni796/robot-security-tshb11
 - \$ git clone git@github.com:matni796/robot-security-tsbb11 (*cd is a terminal command. If your not familiar with navigation in terminal, see http://linuxcommand.org/lc3_lts0020.php)
- 5. Source your own created packages in .bashrc: type: gedit /.bashrc add the line: source wherever_path_you_put_repository/robotsecuritytsbb11/catkin_ws/src/devel/setup.bash
- 6. Install freenect, type:
 - \$ sudo apt-get install ros-groovy-freenect-stack
 - \$ sudo apt-get install ros-groovy-freenect-launch
- 7. Disable gspca kernel according to: http://openkinect.org/wiki/Getting_Started
- cd into the installed folder and into catkin_ws and type catkin_make to build.

1.2 Setup DX100 controller

- 1. Make sure the controller's version supports MotoPlus applications, should be a version ending with -14. Current version (20131206) is DS3.53.01A-14.
- 2. Load parameters. The file ALL.PRM can be found in git repo, under the folder robot/. Transfer it to a cf card or usb. Start the controller regularly. Go into management mode (see below). Then go to EX MEMORY → FOLDER, set folder where you put ALL.PRM. EX MEMORY → LOAD → PARAMETERS → BATCH PARAMETERS ALL.PRM

You might need to do a safety reset of the flash device. This is done by starting up the controller in Maintenance mode. In Maintenance Mode, enter Management mode. INITIALIZE \rightarrow system flash safety reset, might take a while, wait for beep (CHECK NAME). Shut off controller and restart it regularly.

NOTE: Might change the setup of the controller. Should be done with caution. Contact Yaskawa if uncertain.

3. To install MotoPlus application, follow the tutorial on http://wiki.ros.org/motoman_driver/Tutorials/In

• For step 3 in tutorial, see PDF file *MotoPlus Application Installation* in folder *robot*/. Follow the instructions on step 2.1. The application file to be loaded is also in the in the *robot*/ folder.

NOTE: We have used an .out file hardcoded for a SIA20D robot. This version does not come with the motoman files from ROS.

• For step 4 in tutorial, transfer *INIT_ROS.JBI* to CF card or USB device. File can be found under ../catkin_ws/src/motoman/motoman_driver/Inform/DX100/. Start the controller regularly. In menu, go to: Ex MEMORY → FOLDER move to the folder where you put *INIT_ROS.JBI* file. Then: Ex Memory → LOAD → job.

1.3 Setup interface between controller and computer.

Follow the instructions on http://wiki.ros.org/motoman_driver/Tutorials/Usage.

• On step 3, enter the controller IP **192.168.255.1**.

•